

IN BRACKETS. TITI F **APPROVED** DECIMALS INSTALLATION TOOL FOR $.XXX \pm 0.005$ [0.13 mm] REVISED D-141-0113 AND D-141-01140.25 mml ± 0.01 CAD NAME: SOLDERSLEEVES R060291.dwg 0.50 mm] . X ± 0.1 CODE IDENT. NO. DWG. NO. SIZE **ANGLES** AD-1546 THIRD ANGLE 06090 Χ. ± 0.5 DEG **PROJECTION** DO NOT SCALE THIS DRAWING SHEET 1 OF